

Adding a signalTRX unit to the device list in signalCONTROL.

If you wish to administer your device via signalCONTROL, rather than directly via the web GUI, first open signalCONTROL. This can be achieved by visiting the IP address of a signalCORE or signalGLUE server, or by downloading and installing the standalone signalCONTROL app from <https://signal.tv/control> .

To add a new device to the device list in signalCONTROL, ensure that you are in the "Device" tab, then click the '+' icon in the bottom left of the screen, at the bottom of the device list. Select 'Signal Device' from the list, and then either select 'add' next to the auto discovered signalTRX unit, or manually type in the IP address of your signalTRX unit. Auto discovery does not work across subnets as it is using bonjour.

Once added, your signalTRX unit can be administered by selecting it from the device list, then configuring it in the configuration pane on the right of the screen.

Revision #5

Created 16 January 2024 15:30:34 by Admin

Updated 16 January 2024 18:10:01 by Admin