

Outputs

There are 5 routable destinations in the "Outputs" tab. First there are the 3 hardware outputs: HDMI 1, HDMI 2 and SDI. Next is the input to the record/playback module, and lastly there is the "return" input to the Prompt module.

By default, bars is routed to all outputs. This enables you to find out information about your signalTRX unit such as IP address and serial number simply by plugging a screen in.

Routing to an output

The page is split into two columns, with the destination fixed on the right and the source as a dropdown on the left.

To create an output, select a destination from the dropdown list in the bottom middle of the screen and click "set". This will create a new output row. To patch something to the output, select a source from its corresponding dropdown list and then click "set".

If you selected a streaming source, you can edit its details by clicking the cog icon in the top right corner of the source block.

You can use the on/off toggle in the top center of the block to turn a destination on and off.

To change a destination, you can select another from the dropdown list in the destination block and click "set".

Useful information, such as the format and frame rate is displayed in both the source and destination blocks.

Clicking the 'x' at the top corner of the destination block will remove that destination row.

Revision #4

Created 16 January 2024 15:36:19 by Admin

Updated 19 January 2024 10:21:40 by Admin