

# The signalTRX web GUI

- [Network](#)
- [Encoders](#)
- [Outputs](#)
- [Prompt](#)
- [Playback](#)
- [System](#)

# Network

## The network configuration tab

The network configuration tab is split into two halves: Wifi, and everything else.

### On the left

To connect to a discovered SSID, click the connect button and then fill out the authentication details. If successful, the signalRX mini unit will connect to the new wifi network.

To delete a saved SSID, press the "forget" button next to it. For networks not currently discovered, scroll to the bottom of the list, where you will find all saved networks.

To manually add an SSID which is not currently discoverable, press "add manually". Fill out the SSID and authentication details and then press save. The signalRX mini unit will try to connect to this, and if it fails it will try again if this SSID comes in range.

The list of discovered network devices refreshes once when you open the network tab. To manually refresh the list, press the refresh button. The list does not scan continuously to prevent negatively impacting the performance of network roams.

### On the right

To configure your wired network settings, and (for 5G variants) the 5G interface settings, find the adapter settings on the right hand side of the page. By default, each adapter will behave as a DHCP client.

To manually configure network settings, disable DHCP using the toggle button and then fill in fields such as IP address, netmask, gateway and DNS and click update.

Tooltips to the right of each field contain more information that should help you if you're stuck.

Each device can be enabled and disabled using the thus labelled toggle switch.

The 'add to bridge' adds the interface to an internal network bridge. This can be useful if - for example - you wish give wireless network to a device that does not have wifi, and instead only wired network. Simply bridge the WIFI and ethernet ports on the signal unit, then plug the a cable between the ethernet port and the device requiring a network connection.

Selecting "hotspot mode" on the wifi adapter will act in the same way as pressing and holding the 'ID' button on the side of a signalTRX unit. The unit will disconnect from its current wifi network (if it is currently connected), and produce its own network with an SSID matching the unit's serial number, which can be found on the base of the unit. The password will also be the unit's serial number.

# Encoders

The encoders tab is where you go to take an source, encode it and stream it somewhere.

The sygnalRX mini has 1 on board hardware encoder.

The encoders tab is split into three columns: Source, Encoder, Stream. If you have not yet created an encoder, click on the "add hardware encoder" button, then select your chosen codec. This will create a new row with a source, encoder and stream.

## Source

In this column, the user choses from the list of available sources to feed into the encoder. The options are:

Prompter Moudle Out  
Bars Generator  
No Source

Select one of these from the dropdown list, and click 'set'. Changing the source will - obviously - interrupt the streams. So don't do this while on air!

In the top right corner of the stream block is an 'x' which sets the source back to 'No Source'.

Next to this there is a restart button which restarts the input, which can be useful for giving the system a "kick" in the unlikely event that the source changes format and the sygnalRX mini does not detect this change automatically.

In the body of the stream block, useful information is displayed such as the format and frame rate.

In the top left corner of the stream block is a status light. Green means a valid signal is present. Red means there is no valid signal present.

## Encoder

In this column you can configure the encoder profile.

Select the cog in the top right corner of the encoder to change these settings. There are tooltips which describe each parameter in detail. For further details, tooltips contain links to the glossary of terms.

Once you are happy with your changes, press 'set'. Or if unhappy, press 'cancel' to cancel. Changing some parameters in the encoder will cause the stream to stop and restart, dropping a frame or more. If this is the case, a message will alert you to this next to the set button. If you are happy with your parameters and wish to save them as a default, press the "save" button next to the preset dropdown, and give it a name when prompted. If you wish to copy the settings to quickly apply them to another encoder, press the "copy" button and then the "paste" on the destination encoder.

In the top center of the encoder block, there is a toggle switch to enable and disable the encoder.

In the top right of the encoder block, there is a restart button: to restart the encoder; a cog: to configure the encoder; and an 'x' which deletes the encoder.

In the top left of the encoder block is a status light. Green means that the encoder is running and encoding successfully. Red means that the encoder is not currently running and encoding successfully.

## Stream

In the streams column, you can add, manage and delete streaming destinations.

To add a stream, click add, and then configure the streaming destination. There is a field for entering a human readable name like "Jamie's Facebook Live", so that you can easily keep track of which stream is which.

To delete a stream, click the 'x' icon at the top right of a streaming block.

To edit a stream, click the cog icon at the top right of a streaming block. If you are happy with your parameters and wish to save them as a default, press the "save" button next to the preset dropdown, and give it a name when prompted. If you wish to copy the settings to quickly apply them to another encoder, press the "copy" button and then the "paste" on the destination stream.

In the top center of the streaming block there is a toggle switch to turn a streaming destination on or off.

In the top left of the streaming block is a status light. Green means it is successfully streaming to its destination. Red means it is not successfully streaming.

# Outputs

# Outputs

There are 2 routable destinations in the "Outputs" tab. First there is the hardware output: HDMI 1. Next is the "return" input to the Prompt module.

By default, bars is routed to all outputs. This enables you to find out information about your signalRX mini unit such as IP address and serial number simply by plugging a screen in.

## Routing to an output

The page is split into two columns, with the destination fixed on the right and the source as a dropdown on the left.

To create an output, select a destination from the dropdown list in the bottom middle of the screen and click "set". This will create a new output row. To patch something to the output, select a source from its corresponding dropdown list and then click "set".

If you selected a streaming source, you can edit its details by clicking the cog icon in the top right corner of the source block.

You can use the on/off toggle in the top center of the block to turn a destination on and off.

To change a destination, you can select another from the dropdown list in the destination block and click "set".

Useful information, such as the format and frame rate is displayed in both the source and destination blocks.

Clicking the 'x' at the top corner of the destination block will remove that destination row.

# Prompt

# Prompt

The signalPROMPTER is a licensable add-on available for all signal units.

The prompter output is generated on device which means that there is no encoding/decoding latency, allowing for super low latency prompting and smooth scrolling.

## Licensing the prompter

Licenses are sold as time restricted, or perpetual. Licenses can be purchased via a syngalRX mini's web GUI [System page](#) if the unit has an internet connection, or from <https://sygnal.tv/licenses> . Licenses purchased via the website can be installed by copy and pasting or uploading the license key file into the web GUI on the [System page](#).

Once licensed, the prompter can be edited and controlled via the unit's GUI at <http://<device ip address>/prompt> or via the desktop signalPROMPT application, available for Mac, Windows and Linux at <https://sygnal.tv/prompt>.

## Using the prompter via the web GUI

Visit the web GUI for your syngalRX mini unit. Go to the 'Prompt' tab. Here you will find a basic web-based text editor and prompt controls which will allow you to control the teleprompter output of this device.

## Using the prompter via the signalPROMPTER application

Download the latest version of signalPROMPT at <https://sygnal.tv/prompt>

Click the device manager tab, and then click the '+' icon to add the chosen signalRX mini unit. If on the same subnet, it will be auto discovered. If not, you can add it using the device's IP address. Once the device is added to the list, check the "prompting" box next to it, such that your open prompting session begins transmitting data to the signalRX mini unit.

For more information about the signalPROMPT application, please read the [signalPROMPTER product manual](#).



# Playback

The playback module is a simple clip store and slide show module, which enables you to load files on to the signalRX mini and play them out from the HDMI port. The clip player can be controlled via the signalRX device's GUI, or via the signalCONTROL GUI.

# System